

# Friendship Center Sound System Information

## Start up:

- Turn on the red switch inside the cabinet on the top right, next to the word “Master.” That should start up the main mixer, the Bluetooth receiver, and the wireless microphone receivers. You may get an error message about power interruption on the board. Just press “ok.”




**NOTE: Please wait until the mixer is done starting to move to the next step. This takes several minutes!**

- Turn on the power strip—right side of the shelf against the wall—the one that is not lit. This will power up the main speakers.
- Then select your “scene” most groups will use U4. It powers all 4 mics and the Bluetooth input.
- You will want to have “Main Mix” selected on the upper left side of the screen. This will give you control over the sound going to the main speakers. Input list:



- Inputs 1-4 = Microphones 1-4 (2 handheld, 2 belt packs)
- Inputs 5 & 6 = Bluetooth volume
- Inputs 7 & 8 = Aux in



## Shutting Down the Sound System:




- Turn off the main speakers using the power strip (see above)
- Shut Down the Sound board—Press the power button on the back upper right corner of the board. Choose to power down the board and wait for it to shut off.
- Turn off the red switch inside the cabinet.



## Sending Sound to a Computer for Livestream:

There are two outputs on 10' cables for sending sound to computers, a 1/8 inch plug (like an aux or headphone cable), and a USB cable.

- If you have a “mic” input in your laptop use the 1/8 inch plug.
  - You can control the volume on these by adjusting the volume for individual inputs in Aux 2 and 3.
  - Touch the “Aux” buttons under the Main Mix on the left side of the board.
  - Same inputs as the main mix
- If you do not have a mic input use the USB connection
  - You can adjust these volumes on the Aux 4 screen
  - Same inputs as the main mix.



## Connecting to Bluetooth:

- The Bluetooth receiver will power up “master” power switch
- Look for “Radial Eng” in your Bluetooth devices
- The first time you connect you will need the code—1246. This code is printed on the side of the Bluetooth receiver, too.
- Adjust volume on inputs 5 & 6 on all screens

## Using the line-in:

- There is a second 1/8 inch plug coming from the back of the board on a much shorter cable (about 3 feet)
- This is an input into the board from a phone, computer, etc.
- Adjust this volume using inputs 7 & 8 on all screens.